

# How to measure a 10mm frameless shower fixed panel



Using a spirit level check that your wall / floor are plumb and level.

The shower recess must be tiled prior to measuring.

Measure twice – left to right, then right to left – both measurements should be the same.

Don't take measurements until your shower base is installed and your walls are tiled.

## **Step 1: Measure the width of your panel**

If you are installing on tiles you need to measure from the wall to the grout line that indicates the end of the shower area. This measurement will be the width of the panel.

If you are installing on a base, measure from the tiled wall to the base internal recess.

When ordering online select the width that your panel needs to be. Sizes range from 697mm to 1397mm w. Remember there needs to be a 3mm gap between the wall / floor and fixed panel for silicone.

## **Step 2: Measure the height of your panel**

Our fixed panels are 2050mm high. To protect your plaster your tiles must be higher than the shower panel height.

## **Step 3: Selecting wall fixings**

Frameless fixed panels can be attached to walls with either wall brackets, wall channel or rebated into tiles. If you decide to use wall channel instead of wall brackets when ordering online, please let us know and we will replace the brackets with channel.

If you would like to rebate the panel into the tile you can use wall channel.